



## KEY BENEFITS

The Uccello Kettle is a safe and elegant assistive technology, that makes handling boiling water safely seem effortless. In addition, this red and white model provides the required contrast and differentiation which assists people living with dementia and low vision, helping to maintain independence in the kitchen.

### Form & Functionality

Unlike other kettles and kettle-tippers, the circular shape of the Uccello Kettle, combined with its rotating cradle, moves around the body of water to assist the flow of the pour, so you don't have to lift, strain, balance or aim.

### Perfectly Positioned Handle

The positioning and shape of the ergonomically-designed Uccello handle means weight is distributed across the entire arm, not on fingers & wrists, which makes it easier to handle comfortably.

### Easy-Touch Lid

While most kettles require that you awkwardly lift and hold open the spout while refilling, the Uccello's one-touch-to-open hinged lid, requires the lightest of touches to tap open or close. Easy filling is also ensured by the wide opening.

### Safe & Sturdy Base

Uccello's detachable water body vessel sits comfortably within a sturdy base that has the added safety of non-slip feet for further stability of pour.

### Elegant Yet Practical Design

The red and white contrast design of the Kettle colours helps individuals with dementia and low visibility differentiate the important parts of the Kettle, including the easy-touch lid button. This elegant feature is also a safety feature.

### Tapered Spout

From first to last drop of boiling water, the tapered design of the spout ensures water is targeted to the same spot every time, without the splashing experienced with ordinary kettle pours.



### Kettle Features

- Effortless pouring technology
- Stainless steel heating element with British safety technology and control
- Auto shut-off with overheating protection
- Ergonomic handle for easy handling
- Removable stainless steel anti-scale filter
- Water level indicator
- Power-on light
- Large non-slip base
- Quiet boiling

### Technical

6 cup (1.5 litre) capacity

50Hz 120 Volts

### Kettle Materials

Kettle vessel, cradle and base: Polypropylene, a thermoplastic polymer. All plastics in contact with water are BPA free.

Element and controls: Stainless steel

### Kettle Dimensions

L234mm x W120mm x H221mm

(L9.2in x W4.7in x H8.7in)

Weight: 820g (1.85lbs)

### Packaging

#### Retail box

L298mm x W242mm x H247mm

(L11.75in x W9.5in x H9.7in)

Weight: 1,790g (4lbs)

#### Carton

4 units per carton

L508mm x W316mm x H528mm

(L20in x W12.45in x H20.8in)

Weight: 8kgs (15.6lbs)

